

## Moen Slingshot Assembly Instructions

### IMPORTANT:

**Do NOT remove shrink wrap from rod and sling assembly until assembly is complete!**

#### You should have:

- 1 bottom panel – laminate face with inserts facing up, casters downwards.
- 1 top panel, laminate also face up. Inserts are on bottom (brown) side.
- 3 Black back panels with slings and rods attached, panels also have 2 cams each at top and bottom already inserted..
- 12 threaded steel pins.

1. Insert threaded steel pins into inserts on bottom panel
2. Place the 3 black panels onto the base piece (check that panels are right way up, they are labeled on the top edge), fitting the panels over the steel pins.  
**Make sure that arrows on cams at bottom of panels are pointing straight down towards the base piece.**
3. With a screwdriver, turn cams at bottom of panels until snug.
4. Allow bottoms of vertical rods to rest on the ground for now.
5. Insert threaded steel pins into inserts on top panel. **Ensure that arrows on cams (little round silver things) at tops of black panels are pointing straight upwards.** Place top panel onto the 3 black panels ensuring that the steel pins enter the holes in top edges of black panels. **Do not tighten these cams yet.**
6. Insert tops of long rods into holes into top panel, lift very slightly - just enough so that bottoms of vertical rods can be placed over the nuts on the base panel. Ensure that all rods are properly inserted and that the top panel is down tight. **Now, tighten cams.**

Stand back and admire your work, place books into sleeves.



**Any problems? Call us toll free at 1-877-333-6636 or 1-780-469-9770 We care!**  
**E mail: [moen@planet.eon.net](mailto:moen@planet.eon.net)**