



Moen Astro, Flutter, Core, Karma, Luna, Petal, Squabble, Sumo, Leaf and Spin Assembly:

- You must use the enclosed lock washers.
- Start all screws by drill - if desired, but you must tighten screws by hand. However, do not overtighten.
- Karma tables have 6 legs, 2 with casters, 4 without. Note placement of legs as shown.
- Astro and Squabble tables assemble in similar fashion except that they have only 5 legs – 2 with casters, 3 without.
- Flutter, Core, Luna, sumo and Leaf tables each have 4 legs with casters on 2 legs as shown.
- Caster locations are marked with the  symbol.



Any problems? We care! 1-877-333-6636 or by e mail:
moen@planet.eon.net

